



Notes:

1. Depth of saw cut is below resurfacer.
2. Brush or trowel Series 434, 435 or 436 Perma-Shield into saw cut termination.
3. On vertical applications, Series 435 will require Series 211-211 Fumed Silica or other approved bulking powder to fill the 1/4" saw cut.

N.T.S.

**TNEMEC PERMA-SHIELD
STANDARD LINING DETAILS**

LEADING EDGE TERMINATION

NO. PLS-1

REV.1