



NOTE(S):

1. USE FLEXIBLE UNDERLAYMENT TO BRIDGE HAIRLINE CRACKS IN FLOORS WHERE NO EVIDENCE OF SETTLEMENT OR MOVEMENT AND WHERE FLOOR IS NOT EXPOSED TO DRASTIC THERMAL CHANGE.

**TNEMEC TNEMEGUARD  
STANDARD DETAILS**

**MULTIPLE NON-MOVING HAIRLINE CRACKS**

**NO. TGS-12**

REV.0