



NOTE(S):

1. A 1/4" X 1/4" (6.35 MM X 6.35 MM) SAWCUT SHALL BE MADE IN THE CONCRETE ALONG ALL LEADING EDGES OF THE COATING.
2. THE SAWCUT SHALL BE DRIED AND CLEANED OF ALL DUST AND RESIDUE PRIOR TO PRIMING.
3. AREAS NOT TO BE COATED, BUT WHICH ARE ADJACENT TO A LEADING EDGE, SHALL BE NEATLY TAPED OFF AND PROTECTED FROM PRIMER AND TOPCOAT MATERIAL OR OVERSPRAY.
4. PRIMER SHALL BE APPLIED INTO SAWCUT AREAS.
5. APPLY SERIES 154 MORTAR (3 PARTS CLEANED 50-70 SILICA TO 1 PART SERIES 154) OR APPROVED URETHANE SEALANT INTO SAWCUT AREA. FLOOD INTO SAWCUT CAVITY WITH TROWEL OR PUTTY KNIFE, AND SMOOTH LEVEL. VERTICAL WILL REQUIRE 2 OR MORE COATS.

TNESEC TNEMEGUARD STANDARD DETAILS

LEADING EDGE TERMINATION DETAIL

NO. TGS-1

REV.0